

CUTOUT

LOCATE TEMPLATE ON TOP SIDE
SHELF USING DRILLED SLOTS AS
CAUTION: TEMPLATE MUST LINE
UP TO DRILLED SLOTS, CUTOUT
AREA CRITICAL.

TO
FRONT
OF CAR

