5. REMOVE STEERING COLUMN COVER & DRILL HOLE IN REINFORCEMENT.

6. INSTALL PROVIDED U-NUT ON RELAY AND MOUNT RELAY OVER EXISTING SCREW HOLE IN REINFORCEMENT & SECURE WITH SCREW PROVIDED.

CAUTION: POSITION U-NUT & RELAY AS SHOWN.





CIRCUIT DIAGRAM